Please visit www.blueox.com for the latest version of these installation instructions.




## BXW4075 & BXW4076 Hitch Head Kit Installation Instructions

## **▲** CAUTION

Before installing the Hitch Head Kit unhook the trailer from the hitch head. Also remove the assembly bars from the hitch head.

- 1. Remove the existing hitch head from the receiver hitch mount. Do not discard fasteners, they will be reinstalled. If being reused, remove the ball from the existing hitch head and install onto the new hitch head. Torque to manufacture's specifications.
- 2. Install the new hitch head onto the receiver hitch mount in the previously used location, using the existing 3/4" fasteners. Torque the bolts to 260 ft/lbs.



## BXW4075 & BXW4076 Hitch Head Kits Installation Instructions

## **CUSTOMER SERVICE COMMITMENT**

Blue Ox® is committed to providing you with exceptional customer care throughout your lifetime with our products. Our team is here to assist you with any questions you may have regarding the performance of your product. Simply call (402) 385-3051 and you can speak with our customer care team.

Additionally, please visit our website to see which rallies our Destination America team will be attending. For a nominal fee, our service technician will service your towing system to ensure it's in proper working condition. Also, as a commitment to our customers, should you visit our factory, you can stay at our full service Blue Ox® campground at no charge along with enjoying a factory tour.

Again, thank you for being our customer and for the confidence you have shown in the performance of our products. It is because of customers like you we enjoy the success we have today.

