

INSTALLATION INSTRUCTIONS AND PARTS LIST

MODEL 415298, GRIP STEPS (1 BOARD ONLY) UNIVERSAL APPLICATION

1. Read instructions completely and check to make sure that all required parts (listed on the service parts list) are on hand before starting the installation.
2. Follow the instructions included with the specific bracket package to mount the brackets to your vehicle.
3. Step assembly:
 - 3.1 This Board can be modified from its original length to fit many applications. Simply determine how long you will need the board, and cut to that length using a saber saw, chop saw, or hack saw. Use flat black paint to touch up the ends that were cut.
 - 3.2 Before attaching the grip steps to the brackets, slide the appropriate number of support braces (item #2) into the channel of the step (item #1).
 - 3.3 Slide the end cap (item #3) over the front and rear of each step. Using the supplied #8 x 1/2" self drilling tek screw (item #8), screw the end cap to the bottom of the step.
4. Attaching the step to the mounting bracket:
 - 4.1 Set the step on the mounting brackets, and slide each support brace over the top of each mounting bracket. Attach the flat spacer plate (item #4) to the bottom of the step, between the support brace, and the top of the mounting bracket.
 - 4.2 Using the supplied 5/16-18 x 1" carriage bolt, washer, and flange nuts, (item #5, 6, 7), attach the step assembly, flat spacer plate and mounting bracket. **(NOTE: Some of the flange nuts are supplied in the specific bracket package, not the step package.)**
 - 4.3 Set the step plate in the correct position and tighten all fasteners.
Torque all fasteners to 19 LB FT.

SERVICE PARTS LIST

ITEM	PART NO.	QTY	DESCRIPTION
1	551888	1	EXTRUSION-AL,97.87,GRIP STEP,BLK,415098
2	551296	5	SUPPORT BRACE, UPPER, GALV.
3	551394	2	CAP-END,GRIP STEP, BLACK, PLASTIC
4	551298	5	SPACER PLATE, LOWER, BLACK
5	108683	10	BOLT-CRG,5/16-18 X 1.0", SST
6	101369	10	WASHER-FLAT,5/16,SST
7	102680	10	NUT-SERR FLG,HX,SST,WX,5/16-18
8	107958	4	SCR-TEK #8-18 X 1/2",SST,BLK



SERVICE PARTS LIST

MODEL NO. — 415298

