BBK PERFORMANCE LLC / For any questions, email us: 3060 Performance Circle / TECH@BBKPERFORMANCE.COM Deland, FL 32724 /



## **INSTALLATION INSTRUCTIONS - INS116**

# 1999-2004 GM Truck 4.8L & 5.3L // 1999-2009 GM Truck 6.0L 1996-1998 GM Truck 5.0L & 5.7L

# FULL SIZE TRUCK

Part # 4005 and 40050 / 1999-2004 GM Truck 4.8L & 5.3L Part # 4006 and 40060 / 1999-2009 GM Truck 6.0L Part # 4007 and 40070 / 1996-1998 GM Truck 5.0L & 5.7L



SPECIAL TOOLS REQUIRED: No special tools required.



INSTALL TIME: Approximately 1 hour and 30 minutes.



DIFFICULTY: Easy.



IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019

F L 🗄 🔘

BBK PERFORMANCE LLC / For any questions, email us: 3060 Performance Circle / TECH@BBKPERFORMANCE.COM Deland, FL 32724 /



# FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

### STEP 1

Disconnect the negative battery terminal.

### STEP 2

From underneath the vehicle, remove the nuts that attach the Y-Pipe to the factory exhaust manifolds.

### STEP 3

Remove any EGR or air lines going to the exhaust manifolds. Unplug the oxygen sensors. Unbolt and remove the factory exhaust manifolds and the stock gaskets.

### STEP 4

Clean any old gasket material off of the cylinder head, use a scrapper if necessary.

### STEP 5

Using the factory hardware and the Supplied Gaskets install the BBK Headers.

### STEP 6

Attach the Y-Pipe to the BBK headers using the factory hardware.

### STEP 7

Using the supplied hardware, gaskets, and block-offs connect the EGR and AIR fittings to the BBK Headers where applicable.

NOTE!!! Be sure to apply a small amount of the supplied anti-seize on the threads.

### STEP 8

After driving the vehicle and allowing it to cool a few times, go back and re-tighten the header bolts.



IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019

