



**baja designs®**  
*The Scientists of Lighting*

## Honda Talon RTL Kit Instructions 44-7807, 44-7808, 44-7809, 44-7810



185 Bosstick Boulevard • San Marcos • CA • 92069

Phone 760-560-2252 • Fax 760-560-0383

info@bajadesigns.com • [www.bajadesigns.com](http://www.bajadesigns.com)



***baja designs***<sup>®</sup>  
*The Scientists of Lighting*

## **LIMITED LIFETIME WARRANTY**

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

### **Exclusions:**

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.


### **Indemnification:**

**Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies**


### **Tools Required**

- 7/16" Socket Wrench
- 7/16" Wrench
- Electrical Crimpers
- Standard Screwdriver
- 6mm Allen Wrench
- 5mm Allen Wrench
- 10mm Wrench

1. Using a 6mm Allen wrench, remove the 4 circled fasteners. Using a 5mm Allen wrench, remove the 2 bolts on the bottom side of the roof located by the arrows.




2. Place the 1/4"-20 hex bolts into the channel on the RTL. The wiring leads should be on the passenger side for the RTL and both sides for the RTLS.




3. Center the light bar to the car. Using a 7/16" socket, tighten down the light.




4. Remove the back panel in the cargo area with the 2x plastic knobs.




5. Un-pin the grey clip on the left side of the back panel. Unplug the factory harness.



6. Plug in the splice adapter harness into the factory harness on both ends. Re-insert the grey clip back onto the back panel.



7. Locate the battery box in the driver side rear wheel well. Unclip the lid by removing the three fastening clips.



8. Route the RTL harness battery leads through the back panel opening. Using a 10mm socket, attach the ring terminals to the battery.




9. Remove the center console by removing each plastic fastener around the perimeter.




10. Remove the rear vent cover, by taking out the 3 plastic fasteners.




11. Route the harness from the battery through the back panel opening. Route the RTL leads through the vent opening and up the driver side B-Pillar. Route the switches down the center console up to the dash.



12. Remove the plastic splice connector housing from the bullet connector on both taillight leads.



13. Connect the taillight leads to the splice adapter harness. Yellow to Yellow & Red to Red.




14. Finish routing the switches to the dash. Mount in the stock location.



Tie all wires away from sharp, hot, and/or rotating components.

Re-torque all the fasteners after 100 miles.

Your install is now complete! Thank you for choosing Baja Designs.



**RTL-S Diagram**

**I. Turn signal rocker switch**


**II. Reverse Switch:**  
 3/4" Panel mount  
 backlight switch

**V. RTL Leads:**  
 Black – Ground  
 Red – Running  
 Yellow – Brake  
 Blue - White

**VII. Taillight Splice Leads:**  
 Red – Running/Amber  
 Yellow – Brake/Amber

**II. Battery Leads:**  
 Red – Positive (+)  
 Black– Ground (-)

**IV. Dust Light Switch:**  
 21mm x 37mm



**RTL Diagram**

**RTL Leads:**  
 Black – Ground  
 Red – Running/Amber  
 Yellow – Brake/Amber  
 Blue - White

**Taillight Splice Leads:**  
 Red – Running/Amber  
 Yellow – Brake/Amber

**Reverse Switch Lead:**  
 3/4" Panel mount  
 backlight switch

**Battery Leads:**  
 Red – Positive (+)  
 Black– Ground (-)