



baja designs®
The Scientists of Lighting

2019-On Mercedes Sprinter Van Dual S1 Reverse Kit Instructions



185 Bosstick Boulevard • San Marcos • CA • 92069

Phone 760-560-2252 • Fax 760-560-0383

info@bajadesigns.com • www.bajadesigns.com



baja designs[®]
The Scientists of Lighting

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture. These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:

Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.

****For a color copy of instructions, visit your vehicle specific application on BajaDesigns.com ****


Tools Required

- * T-15 Torx Bit
- * 10mm, 7/16" Wrench
- * 7/16" Socket

- * Phillips Screw Driver
- * Drill Bit Assortment

1. Using a T-15 Torx Bit, remove the 4x bolts securing the reverse camera.

2. Once the fasteners are removed, place the 4x supplied spacers into the cavities.



3. Place the bracket on top of the spacers. Using a philips screw driver and the 4x supplied screws, fasten down the bracket. Using a 7/16" wrench and socket, fasten down the lights to the bracket.



4. Using a 10mm wrench, attach the power leads on the harness to the battery. Route the harness through the boot on the firewall.



5. Route the harness under the dash from the firewall to the back of the vehicle.



6. Use the 3x 10' extension harness where needed to reach the back of the vehicle.




7. Once the rear doors are reached, route the wires through the OEM door wiring pass through. Use silicone or any sealant to prevent leaks in the rubber. Route the wires up the door seal to the lights, Use the supplied splitter harness to attach the two lights to the harness.



8. Run the wire switch leads to the factory switch panel. Either drill a 3/4" hole to mount the supplied toggle switch, or see step 9.



9. If an OEM look is desired, locate an OEM dash switch to replace any of the blank switch covers. Agile Off-road carries them for the VS30. Ensure the OEM switch is pinned correctly, remove the toggle switch on the supplied Baja Designs harness & hook up to the OEM terminals. The terminals on the Baja Designs harness are as shown.



Tie all wires away from sharp, hot, and/or rotating components.

Re-torque all the fasteners after 100 miles.

Your install is now complete! Thank you for choosing Baja Designs.