


Steering Column Boot Trimming Instructions **I-10**

This boot comes with a 5/8" column hole. This hole can be trimmed to fit steering columns up to 2-1/2" diameter. Be sure to measure your steering column diameter prior to trimming.

To cut the rubber steering column boot we find that a sharp pointed Xacto type razor knife works best. Take your time and proceed with the cut slowly and carefully for the best results.

Cut boot one ring smaller than your actual steering column diameter to insure a tight fit to the steering column. This will result in a "stretch fit" over your column for a nice tight seal. See table and illustration below for location of cuts.

- 3/4" Diameter. No cut required.
- 1-1/2" Diameter. Cut at first ring.
- 2" Diameter. Cut at second ring.
- 2-1/2" Diameter. Cut at third ring.



Trimming instructions apply to all three styles of firewall boots shown below



1987-1995 Jeep Instructions

I-10

****IMPORTANT**** The gray protective coating is on the polished side of the bezel. DO NOT remove protective film until you are ready for final installation. A 35% restock fee will apply to all items returned without protective film.

Follow instructions for trimming the column boot to your specific diameter on the previous page.

Using the stainless trim plate as a template with the gray protective film facing out mark the three mounting holes on your fire wall as shown in photos below.

Use a 9/64" drill bit and drill out the three marked holes.

Slide boot over column and attach the stainless trim plate with the three stainless steel screws provided.

