

## Installation Guide for Hyundai Kona N PNs 140926, 140926BC



**\*\*\*\*\* Please compare the parts in the box with the bill of materials provided \*\*\*\*\*  
to ensure that you have all the parts necessary for this installation.**

These instructions have been written to help you with the installation of your Borla Performance exhaust system. Please read this document completely before beginning the installation of your system.

To ensure this part number fits your specific model year, please visit our website for the latest model year listings at [www.BORLA.com](http://www.BORLA.com)

Thank you for purchasing a Borla Performance Cat-Back™ exhaust system.

This Borla Performance Cat-Back™ exhaust system PNs 140926 and 140926BC are designed for the Hyundai Kona N, equipped with a 2.0L inline-4 turbo-charged engine and FWD manual or automatic transmission.

Borla Performance Industries recommends that an exhaust shop or professional after market parts installer, who has all the necessary equipment, tools and experienced personnel needed for proper installation, should perform the installation of this system. However, if you decide to perform the installation, we recommend someone should help you. Ensure the installer uses all under car safety precautions including eye protection.

*Please take time to read and understand the following...*

By installing your Borla Performance exhaust system, you indicate that you have read this document and you agree with the terms stated below.

It is the responsibility of the purchaser to follow all installation instruction guidelines and safety procedures supplied with your Borla Performance exhaust system.

Borla Performance Industries assumes no responsibility for damages occurring from misuse, abuse, improper installation, improper operation, lack of responsible care, or all previously stated reasons resulting from incompatibility with other manufacturer's products and/or systems.

Included with your Borla Performance exhaust system is a warranty card. Please read it carefully before you begin any work on your vehicle. If you should have any questions regarding our warranty policy, installation, or any other matter pertaining to your new Borla Performance exhaust system, please give us a call at the number provided on the warranty card.

**Minimum Required Tool List:**


**TOOLS:**

1. 3/8" drive ratchet
2. 3/8" drive extension 6"
3. 8mm socket
4. 15mm deep well socket
5. 19mm deep well socket

**SHOP SUPPLIES:**

1. Spray lubricant

**Borla Performance - Bill of Materials**



**140926/BC**

ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	58039	FRONT PIPE ASSEMBLY
2	1	58036	MID PIPE ASSEMBLY
3	1	57323	Y-PIPE ASSEMBLY
4	1	58038	R/H TAILPIPE ASSEMBLY
5	1	58037	MUFFLER ASSEMBLY
6	4	90114	3.00 ACCUSEAL CLAMP

EXHAUST SYSTEM WITH BLACK CHROME FINISH TIPS WILL BE 140926BC

**Caution!!!** *Never work on a hot exhaust system. Serious injury in the form of burns can result if the vehicle has been in use and the exhaust system is hot, allow vehicle to cool for at least 1 hour. Always wear eye protection when working under any vehicle.*

**Note:** *It is our recommendation that you use a hoist or hydraulic lift to facilitate the installation of your new Borla Performance Exhaust System.*







**Taking all under car safety precautions, lift the vehicle using a hoist or hydraulic lift. Once this has been done, you may begin the removal of your old exhaust system from your vehicle.**

**Note:** *Before removing the original exhaust system from your vehicle, please compare the parts you have received with the bill of materials provided on the previous page to assure that you have all the parts necessary for the installation of your new Borla Performance Exhaust System.*

**Note:** *With a used vehicle, we suggest a penetrating spray lubricant to be applied liberally to all exhaust fasteners and allowing a significant period of time for the chemical to lubricate the threads before attempting to disassemble.*


## Original Exhaust System Removal

1. Lubricate all hangers, rubber isolators, bolts and nuts.
2. Disconnect the wiring connector to the exhaust valve actuator (Fig. 1).
3. Loosen and remove the hardware on the rear muffler assembly flange and remove the hanger from the rubber isolator (Fig. 2).
4. Using a flathead screwdriver or a prybar, remove the rear muffler assembly isolators from their hangers on the vehicle and remove the rear muffler assembly from the vehicle (Figs. 3-4). Remove the rubber isolators from the rear muffler assembly to be installed on your Borla system.
5. Loosen and remove the hardware on the front pipe assembly flange (Fig. 5). Keep the hardware for later reinstallation.
6. Remove the front pipe assembly by sliding it toward the rear of the vehicle without removing the under chassis braces (Fig. 6).
7. Remove the exhaust valve actuator to be used on your Borla system by loosening and removing the hardware connecting it to the rear muffler assembly (Fig. 7). Keep the hardware for installation onto your Borla system.



## Borla Performance Cat-Back™ Exhaust System Installation

1. Orient the components on shop floor according to Borla bill of materials drawing on page 2.
2. Install **Front Pipe Assembly** by mating the flange to the vehicle. Loosely tighten the original hardware on the flange (Fig. 8).
3. Place a clamp over the expanded end of the **Mid Pipe Assembly** and insert the inlet to the **Front Pipe Assembly** (Fig. 9). Do not tighten the clamp.
4. Place a clamp over the expanded end of the **Y-Pipe Assembly** and insert the inlet to the **Mid Pipe Assembly**. Insert the hanger into the original rubber isolator (Fig. 10). Do not tighten the clamp.
5. Install the original rubber isolators onto the **R/H Tailpipe Assembly** and **Muffler Assembly** hangers in the same orientation as they were on the original exhaust system (Fig. 11).
6. Place a clamp over the expanded end of the **Muffler Assembly** and insert the inlet to the **Y-Pipe Assembly**. Place the isolator over the hanger on the vehicle (Fig. 12). Do not tighten the clamp.
7. Install the exhaust valve actuator onto the Borla exhaust valve bracket found on the **R/H Tailpipe Assembly** by lining up the spring to the top of the valve and securing with the original hardware (Fig. 13).
8. Place a clamp over the expanded end of the **R/H Tailpipe Assembly** and insert the inlet to the **Y-Pipe Assembly**. Place the isolator over the hanger on the vehicle and connect the wiring harness to the exhaust valve actuator (Fig. 14). Do not tighten the clamp.
9. Once position has been determined to be correct, tighten the hardware on the **Front Pipe Assembly** and then tighten the Accuseal clamps to 32-35 lbs.
10. Before starting your vehicle, make sure to check all wires, hoses, brake lines, body parts and tires for safe clearance from the exhaust system.
11. Start the vehicle and check for any leaks. If any leaks are found, determine cause (such as loose or incorrectly positioned clamp) and repair as necessary.



**WARNING:** Use extreme caution during installation. Torque all fasteners according to manufacturer's torque values and tightening sequence. **DO NOT** use air impact tools to tighten fasteners on Borla Performance Exhaust Systems. Use of such tools may result in bent flanges or gasket contact areas leading to exhaust leaks.

**NOTE:** When you first start your vehicle after the installation of your new Borla Performance Exhaust System, there may be some smoke and fumes coming from the system. This is a protective oil based coating used in the manufacturing of mandrel bent performance exhaust tubing. This is not a problem and will disappear within a very short period of time after the exhaust has reached normal operating temperatures.