

# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Volvo	XC70



## WIRING LOCATION GUIDE

### SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S9 - Ceiling panel

## CUSTOM WIRING HARNESS



## NOTICE

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

Flat blade screwdriver	Panel trim removal tool
Ratchet	Wire stripper
Ratchet extension	Wire crimper
10mm socket	Cutting tool

## ⚠ WARNING

The battery connection must be fuse-protected, 10-amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side  
Tail / Running Circuits - 6.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Open the vehicle tailgate. Remove all trunk floor coverings (A).

## Step 2

Locate and remove the ceiling light in the rear ceiling panel . Separate the connector taking care not to damage the locking tabs (B,C,D).

## Step 3

Remove the ceiling panel section by removing the bolt underneath the removed ceiling light. Use a panel trim removal tool to aid in removing the ceiling panel section. Take care not to damage the alignment tabs on the back (E,F).

## Step 4

Locate the vehicle wiring harness connector under the removed ceiling panel. The connectors will be similar to those on the custom wiring harness. Separate the connectors taking care not to damage the locking tabs (G).

## Step 5





Remove the side trim panels on both sides of the trunk. Locate and remove the fastener for the center side trim panel (H). Remove the upper trim panels by pulling downward, taking care not to damage the alignment tabs on the back (I,J).

## Step 6

Locate and remove both access panels on each side of the side trim panels (K).

## Step 7

Locate the vehicle taillight wiring harness connectors behind the removed access panel on the back of both taillights. The connectors will be similar to those on the custom wiring harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs (L).



# INSTALLATION / SAFETY INSTRUCTIONS

## Step 8

Starting on the driver side, insert the custom wiring harness end with the yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

## Step 9

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

 **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## Step 10

Route the custom wiring harness ends with the red and green wire up behind the interior side panel. Insert the custom wiring harness end with the red wire between the separated vehicle connectors located in the ceiling. Make sure the connectors are fully inserted with locking tabs in place (M,N).

## Step 11

Route the custom wiring harness end with the green wire across the top and down behind the interior side panel to the vehicle and taillight connectors. Insert the custom wiring harness end with the green wire between the separated vehicle connectors. Make sure the connectors are fully inserted with locking tabs in place (O).

## Step 12

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the provided double-sided tape (P).

## Step 13

Route the black power wire from the vehicle battery as shown on the included CME-PCL-INS sheet.

## Step 14

Route the 4-flat down along the side trim panel and out the bottom. When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties (Q).

## Step 15

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

