

INSTALLATION MANUAL

Level of Difficulty

Easy


Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Wiring Location(s)

S1 and S2

Wiring Location Guide* for SUVs and Vans (S)

S1	Behind driver side taillight housing
S2	Behind passenger side taillight housing
S3	Behind driver side rear access panel
S4	Behind passenger side rear access panel
S5	Behind driver side rear bumper
S6	Behind center of rear bumper
S7	Behind passenger side rear bumper
S8	Under rear floor panel
S9	Behind driver side rear access panel
S10	Behind passenger side rear access panel



* Representative vehicle shown

Tools Required

Ratchet	Torx bit, T-27
Socket extension	Panel trim removal tool

⚠ WARNING

Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Be sure to not lay tools across the positive battery terminal (typically noted with red covers or a red '+' symbol). This can cause a ground to short causing sparks and / or electrical shocks.

Product Photo



NOTICE

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

All steps must be followed to ensure the product will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

Maintenance

Periodic inspection of all wires and connections should be performed to ensure there is no visible damage or loose connections.


Step 1

Locate the vehicle battery and disconnect the negative battery terminal. Be sure to fasten this wire down and away from the battery while completing the installation process.



Step 2

Open the rear hatch and locate the taillight trim panel. Use a panel trim removal tool to remove the push fastener in the taillight trim and remove the taillight cover.



Step 3

Using a T-27 torx bit, remove the single screw securing the taillight. Remove the taillight at a 45° angle out from the vehicle (Several alignment tabs will only allow the light to be removed in this direction).

Locate the vehicle taillight wiring connectors. The connectors will be similar to those on your new custom wiring product. Separate the connectors from the taillight housing taking care not to damage the locking tabs. Set the taillight aside.

Repeat steps 2 and 3 on the other side of the vehicle.



How to Fishwire


A) Fish wire is a way to push or pull an electrical wire through a blind hole. Make sure the wire is long enough to stick out on the other side.

Insert the fish wire through the blind hole and locate it on the other side.

B) Use tape to secure the harness to the fish wire and pull back up.

The fish wire or harness may get hung up on something, if this happens you may have to push back down, wiggle it around or twist the wire to loosen it from what it's hung up on.

Fish wire could be anything from a cut-up wire hanger, stiff wire, rope or string depending on what is needed for the installation.



Step 4

Route a fishwire down between the bumper cover in the further rear opening of the bumper cover and the body of the vehicle. Repeat on the other side of the vehicle.



Step 5

Starting on the passenger side, locate the housing with the green wire on the custom wiring harness. From under the vehicle bumper, attach the harness to the fishwire and pull the harness up to the taillight cavity. Attach the custom wiring harness to the vehicle factory wiring and secure to the taillight.


Set the taillight inside the taillight cavity, but do not fully install at this time.



Step 6

Route the housing with the yellow wire above the bumper mount and along the bumper to the driver side. Zip tie as needed along the bumper. Route above the driver-side bumper mount.

Repeat step 5 to the housing with the yellow wire.



Step 7

Locate a grounding point such as an existing screw or bolt in the frame of the vehicle or drill a 3/32" pilot hole. The area should be free from rust, dirt, and paint (abrasive pad/paper to remove rust and paint). Secure the white ground wire with the ring terminal on the existing fastener or with the provided ground screw.

CAUTION

Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury



Step 8


Reinstall the taillights and tighten the zip ties on the green wire. Secure any excess wire so that it is not drooping or dangling, but not so tight that it causes unnecessary strain to the wire which could lead to breakage over time.

NOTICE

Once the RV harness is installed, verify that the harness is functioning by attaching the 4-flat to any vehicle with functioning trailer lights. The taillights on the tow vehicle should function along with the taillights on the towing vehicle.


Step 9

Route the 4-flat along the sub frame along the passenger side and above the rear suspension and drive line. Once you reach the rear of the fuel tank, route between the tank and frame to the rear of the front tire.



Step 10

Pull the 4-flat up between the inner and outer fender route under the weather strip around the back of the engine compartment to the front of the vehicle.



Step 11

Secure any excess wire so that it is not drooping or dangling, but not so tight that it causes unnecessary strain to the wire which could lead to breakage over time. After removing slack from the 4-flat wire, tighten any zip ties and add as needed. Use a zip tie to fasten any excess wire to a solid spot along the driver-side inner fender.

Reinstall all items removed during install. If it was disconnected at the beginning of the installation, reconnect the negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.