

# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Chevrolet	Impala


## WIRING LOCATION GUIDE

### PASSENGER CARS (P)

Representative vehicle shown below

P2 - Behind passenger side taillight housing, outside of trunk

## CUSTOM WIRING HARNESS



## NOTICE

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

Flat blade screwdriver

Panel trim removal tool

## **⚠ WARNING**

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Open the vehicle tailgate. Remove the plastic fastener and wing nut on both sides of the vehicle securing the rear scuff panel. Remove the scuff panel by pulling out on the bottom and then up. Take care not to damage the alignment tabs on the back (A).

## Step 2

On the passenger side, pull back on the felt trunk liner to reveal three plastic wing nuts securing the taillight in place (B). Remove the plastic wing nuts and pull passenger side taillight away from the vehicle taking care not to damage the alignment tabs (C).

## Step 3


Under the passenger side taillight locate the vehicle taillight wiring harness connectors (C). The connectors will be similar to those on the custom wiring harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs (D).

## Step 4

Insert the custom wiring harness end between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place (E).

## Step 5

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

 **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## Step 6

Remove the grommet behind the taillight housing and make a small slit from the outside of the grommet to the center. Route the 4-flat wire through the grommet to the inside of the trunk and re-seat the grommet (F).

## Step 7

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

## Step 8

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

