

INSTALLATION INSTRUCTIONS

⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

APPLICATIONS

Make	Model
Buick	Envision


WIRING LOCATION GUIDE

SUVS, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S5 - Behind driver side rear bumper

CUSTOM WIRING CONNECTOR



NOTICE

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

For initial test, reset electrical system of the vehicle by temporarily removing the vehicle key from the ignition.

TOOLS NEEDED

Flat blade screwdriver

Cutting tool


⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 7.5 amps per side

Tail / Running Circuits - 7.5 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.



INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Locate the vehicle taillight wiring harness connector behind the rear tire, along the frame rail. The connector will be similar to the one on the custom wiring connector (A). Separate the connector from the weather seal connector taking care not to damage the locking tabs (A).

Step 2

Insert the custom wiring connector end into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place.

Step 3

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

Step 4

Open the vehicle trunk. Locate and open the storage compartment on the driver side of the cargo area (B,C).

Step 5

Locate the fuse panel and insert the two provided relays in the location shown (D).

