

# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Chevrolet	Equinox



## WIRING LOCATION GUIDE

### SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S6 - Behind center of rear bumper

## CUSTOM WIRING CONNECTOR



## NOTICE

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

Flat blade screwdriver

Cutting tool

## ⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 7.5 amps per side

Tail / Running Circuits - 7.5 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Locate the vehicle wiring connector along the rear bumper. The connector end will be similar to the one on the custom wiring connector (A). Separate the vehicle connector from the weather seal connector taking care not to damage the locking tabs (B).

## Step 2

Insert the custom wiring connector end into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place.

## Step 3

When in use, route the 4-flat out from the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties.

## Step 4

Install the provided 4-flat dust cover to help prevent corrosion.

## Step 5

Open the vehicle tailgate. On the driver side, locate the fuse access panel cover on the side trim and remove it (C).

## Step 6

On the fuse panel, locate positions K2 and K3 as shown on the fuse cover (D,E). Install the provided relays.

## Step 7

Reinstall all items removed during install.

