



INSTALLATION INSTRUCTIONS DUAL REMOTE FILTER MOUNT PART # 25707

Please read these instructions completely before beginning installation

KIT CONTENTS

QTY.	DESCRIPTION
1	Dual Filter Mount
2	Filter Nipple
2	1/2" NPT Plugs

TOOLS NEEDED

7/8" Open End Wrench
Standard Screw Driver
1/8" Allen Wrench
Drill Motor
3/16" Drill Bit
Thread Sealant Tape

IMPORTANT

The dual filter Mount is machined with 1/2" NPT Ports and requires thread sealant tape or a suitable sealant. Be sure not to over tighten fittings.

FILTER MOUNT INSTALLATION

1. Choose a convenient location for the dual filter mount. Make sure there is enough space for future servicing of the oil filters. Suggested Locations: Firewall, Radiator Support, Fender well.
2. Take the filter nipple(s) supplied, making sure the shorter end of threads are installed onto the dual filter mount. The larger end of the threads will be used for the filters.
3. Using the filter mount as a template, mark and drill three 3/16" holes.
3. Using Sheet Metal Screws (Not included), install the dual filter mount onto the vehicle.
4. This dual filter mount is equipped with two "IN" ports and two "OUT" ports which allows for 4 routing configurations (ports are marked by the arrows). Determine the best routing option for your application. Using thread sealant tape install one hose barb or adapter fitting (Not included) to a "IN" port and one to a "OUT" port. Next install the 1/2" NPT plugs into the two remaining ports.



Warning: Do not over torque fittings.

5. Carefully route hose over to the dual filter mount (hose not included). Be sure to connect In/Out Hose to the correct port. Use filter mount arrows for flow direction.

Note: Keep hoses away from sharp edges, moving parts and exhaust. Do not bend hose sharper than a 5" radius.

6. Apply a light coat of oil onto the o-rings of your new oil filters (not supplied) and install on the filter mount.

VEHICLE TESTING

1. Start the engine and quickly check all connections for leaks.
2. Turn-off the engine and check the oil.
3. Add oil as needed.

Warning: Installation of accessories should only be undertaken by those with mechanical knowledge and are familiar with working on vehicles. Always use eye protection (goggles, safety glasses or shield). Park the vehicle in a well lit area, on level ground and apply the parking brake. Only work on a cold vehicle that has been sitting overnight, failure to do so will result in severe burns and injury. Before starting the vehicle, make sure no tools or any other items are left under hood that could interfere with or be drawn into moving parts of the engine. Failure to follow instructions can lead to severe damage and personal injury.