



INSTALLATION INSTRUCTIONS

ENGINE SANDWICH ADAPTER KIT

PART # 25730, 25733, 25734 & 25770-25774


KIT CONTENTS

QTY.	DESCRIPTION
1	Sandwich Adapter
1	O-ring
1	Sleeve Nut

Please read these instructions completely before beginning installation

IMPORTANT

In most cases the Factory Oil Filter will work with the supplied sandwich adapter. In some applications where the frame or exhaust system interferes with the new filter depth we recommend using a shorter filter length. See the chart below for possible filter options.



THREAD SIZE	LABEL COLOR	FRAM FILTER HEIGHT	FRAM P/N	WIX FILTER HEIGHT	WIX P/N	FRAM FILTER HEIGHT	FRAM P/N	WIX FILTER HEIGHT	WIX P/N
3/4-16	YELLOW	4.92	PH3600	4.83	51516	3.34	PH3614	3.4	51348
13/16-16	BLUE/RED	4.94	PH3429	4.83	51045	3.36	Ph3506	3.4	51042
18mm x 1.5	WHITE	4.94	PH3980	4.83	51036	3.36	PH3387A	3.4	51040
20mm x 1.5	BLACK	3.47	N/A	N/A	N/A	3.39	PH3950	3.14	51381
22mm x 1.5	GREEN	4.94	PH3750	4.57	57026	3.98	PH2	3.43	57060

VERIFYING SLEEVE NUT THREAD SIZE


Included in this kit should be a sleeve nut with thread specification as indicated by the part number purchased and the product packaging. The thread size can be verified by screwing the male end of the Sleeve Nut into the new or old engine oil filter. If it is incorrect, please contact your dealer.

SANDWICH ADAPTER INSTALLATION

The Sandwich Adapter fits between the oil filter and the engine block. Before removing the oil filter, check the clearance between the bottom of the filter and the closest vehicle obstruction. If there are none, then proceed with the installation. If you determine that the stock filter will not fit, refer to the Filter Chart for alternative filter heights.

1. Remove the factory oil filter from the vehicle.
2. Remove the colored label from the Sleeve Nut (if there is one).
3. Take the Sandwich Adapter and two Hose Barb Fittings (Not Provided). Using Thread Sealant Tape or a suitable sealant, screw the Hose Barb Fittings clockwise into the Sandwich Adapter until snug. (See Diagram #2)
4. Using a wrench tighten the two Hose Barb Fittings.
5. Take the O-ring provided, apply a thin film of oil and install into the O-ring groove on the Sandwich Adapter. (See Diagram #2)
6. Making sure the engine block filter landing is clean from oil and dirt, take the Sleeve Nut, Sandwich Adapter, O-ring, and install onto engine sliding the Sleeve Nut thru the Sandwich Adapter. Turn sleeve nut clockwise onto the engines filter nipple. (See Diagram #2)
7. Using a torque wrench, torque the Sleeve Nut to 20 ft. lbs.

Diagram #2



ROUTING HOSES (HOSE SOLD SEPARATELY)

1. Install both ends of the hose onto the Hose Barb Fittings, forming a loop.
2. Take the looped end and route the hose to the oil cooler making sure to stay clear of sharp objects, exhaust systems, etc.
Note: All bends in hose need to have a minimum radius of 5" or the diameter of a small coffee can.
3. Cut and attach hoses to the oil cooler. Secure hoses using zip ties.

SYSTEM CHECK

1. Before starting the vehicle, check engine oil level and add accordingly.
2. Always check fluid levels on a flat surface.
3. After installation and vehicle has completely warmed up, recheck fluid level and inspect all connections for leaks.

Warning: Installation of accessories should only be undertaken by those with mechanical knowledge and are familiar with working on vehicles. Always use eye protection (goggles, safety glasses or shield). Park the vehicle in a well lit area, on level ground and apply the parking brake. Only work on a cold vehicle that has been sitting overnight, failure to do so will result in severe burns and injury. Before starting the vehicle, make sure no tools or any other items are left under hood that could interfere with or be drawn into moving parts of the engine. Failure to follow instructions can lead to severe damage and personal injury.