

ATAC ADVANCED THERMAL ACOUSTIC COATING

APPLICATION INSTRUCTIONS

(INTERIOR USE ONLY)

SURFACE PREP:

- SURFACE SHOULD BE CLEAN AND FREE FROM OIL, GREASE, WAX, & CONTAMINANTS.
- RUST SHOULD BE REMOVED OR TREATED. BARE METAL SHOULD BE PRIMED, WE RECOMMEND A RED OXIDE PRIMER
- PAINTED SURFACES SHOULD BE SCUFFED BEFORE APPLYING
- DO NOT APPLY IN TEMPERATURES BELOW 60°F. (DO NOT LET FREEZE)
- THE SURFACE TEMPERATURE SHOULD BE NO LOWER THAN 60°F

APPLICATION PROCEDURE:

(CAN BE BRUSHED/ROLLED ON OR SPRAY APPLIED)

(SPRAY GUN AVAILABLE THROUGH DEI #50209)

- STIR BEFORE USE (DO NOT OVER-STIR OR SHAKE)
KEEP CONTAINER SEALED & AIRTIGHT FOR STORAGE
- TEST ANY SECTION IN A SMALL AREA
 - PRIME OVER GALVANIZED SURFACES
- APPLY UNIFORM WET COAT OF 12-16 MILS THICK
 - A SECOND COAT CAN BE APPLIED IF NEEDED
 - ALLOW 12 HOURS BETWEEN COATS
 - ALLOW 24 HOURS @ 70°F TO CURE BEFORE COVERING WITH ANY MATERIALS OR EXPOSING TO HEAT FROM ENGINE/EXHAUST SYSTEMS
 - HIGH HUMIDITY & LOWER TEMPS WILL INCREASE DRYING TIME
- DO NOT FORCE DRY WITH HEAT
- CLEAN UP WITH HOT WATER & SOAP

