



Performance Oil Catch Can Kit

Part Number: 860-011

Acura 2021-2025 TLX 2.0L Turbo

Installation Instructions

For technical inquiries please email us at tech@hpsperformance.com

In the email, please include the following information for faster response:

- Year / Make / Model / Engine of your vehicle
- If it is a fitment issue, please include pictures showing the fitment problem
- If there are missing parts, please list the part number(s) from the bill of materials on the 2nd page
- Optional but recommended – Your contact phone number and preferred call back time

You can also give us a call via 626-747-9200 for tech support Monday-Friday, 9:00am-5:00pm Pacific Time.

Bill of Materials

Kit Number: 860-011

Line #	Description	Part Number	Qty
1	Oil Catch Can	OCC-14	1
2	Oil Catch Can Bracket	OCC-BRKT-015	1
3	Straight Aluminum Adapter, AN-6 to 16mm x 1.50	AN816-6-M1615	2
4	Push-On Aluminum Hose End, AN-6, 30 Degree	150-3006	2
5	150 Series Push-On Hose, AN-6	150-06	26 inches
6	150 Series Push-On Hose, AN-6	150-06	16 inches
7	Fuel Injection Hose Clamp, 16mm-18mm	FIC-16	2
8	Bolt, M5 x 0.8, 12mm Long	HW-B5-12	3
9	Bolt, M6 x 1.0, 20mm Long	HW-B6-20	1
10	Flat Washer, M6, 16mm OD	HW-FW6L	1
11	Flange Nut, M6	HW-N6	1

- **Before installing any parts of this oil catch can kit, please read the instructions thoroughly.**
- **Verify the contents of this oil catch can kit before disassembling your vehicle.**
- **Report any defective or missing parts to HPS directly. The HPS dealer you purchased this product from might not have the replacement parts you need.**
- **Installation requires moderate mechanical skills. A qualified mechanic is highly recommended.**
- **Do not attempt to install the oil catch can kit while the engine is hot.**
- **This installation may require the removal of coolant lines that may be hot.**
- **For technical inquiries, please email us at tech@hpsperformance.com**

PLEASE READ CAREFULLY BEFORE INSTALLATION!

This installation is not for the novice customer. Install this product with EXTREME caution! Misuse of this product can destroy your engine! If you are not mechanically inclined, please have a professional automotive mechanic install this kit.

NOTE: HPS holds no responsibility for any engine damage that results from misuse of this product.


GETTING STARTED

1. Turn the ignition OFF and disconnect the vehicle's negative battery cable. If the engine has run within the past two hours let it cool down.


NOTE: Disconnecting the negative battery cable erases pre-programmed electronic memories. Write down all memory settings before disconnecting the negative battery cable. Some radios will require an anti-theft code to be entered after the battery is reconnected. The anti-theft code is typically supplied with your owner's manual. In the event your vehicle's anti-theft code cannot be recovered, contact an authorized dealership to obtain your vehicle's anti-theft code. We also highly recommend NOT discarding any stock parts after the installation.




2. Remove engine cover.



3. Remove the two bolts and one nut from the driver side strut tower (indicated in the image above).




4. Lift up the factory brace to gain access to install the oil catch can bracket. Place the large hole of the catch can bracket over the strut tower bolt and secure it using the factory nut removed in step 3.




5. Place the provided M6 bolt and washer at the rear mounting point to hold the catch can bracket to the rear of the factory brace, then reinstall the factory bolt to secure the factory brace.




6. Use the provided M6 nut to secure the M6 bolt at the back of the catch can bracket. Then, fasten all of the hardware installed.




7. Unscrew the top of the HPS Oil Catch Can and check that the Allen bolts are tight.




8. Secure the oil catch can to the oil catch can bracket using the three provided M5 Allen head bolts.




9. Install the provided AN-6 to 16mm x 1.50 adapters onto the oil catch can.




10. Remove the engine cover grommet stud.



11. Lift up the engine harness to gain access to the hose clamp indicated in the picture above. Depress the clamp and disconnect the vacuum hose from the valve cover.




12. Depress the clamp and remove the vacuum hose at the intake manifold.



13. Connect the 26" long push-on hose to one of the provided 30 Degree AN-6 fittings. Use the provided hose clamp to secure the opposite end of the hose onto the valve cover vacuum bung. Then fasten the AN fitting to the oil catch can.



14. Connect the 16" push-on hose to the remaining 30 Degree AN-6 fitting. Use the provided hose clamp to secure the opposite end of the hose on the intake manifold. Fasten the AN Fitting to the oil catch can.



15. Reinstall the engine cover grommet stud.



16. Reinstall engine cover.

FINAL STEPS


Upon completion of the installation, reconnect the negative battery terminal before you start the engine. Double check to make sure everything is tight and properly positioned before starting the vehicle.

Start the engine. Let the car idle for 3 minutes. Perform a final inspection before driving. Listen carefully for any odd noises or rattles prior to taking it for a test drive. If any problems arise, go back and check the hoses and clamps that may be causing the issue and correct the problem.

Ensure that the dipstick on the HPS oil catch can is fully seated. Failure to install the dipstick properly will result in a check engine light and poor performance.



**Also available for:
Acura 2021-2025 TLX 2.0L Turbo**



HPS Performance Air Intake Kit
Part Number [827-731](#)



HPS Magnetic Oil Drain Plug
Part Number [MDP-M14x150](#)



HPS Performance Air Filter Cleaning Kit
Part Number [HPS-AFRC](#)

**Contact an authorized HPS Performance dealer or
visit us at [hpsperformance.com](https://www.hpsperformance.com) for more details**