




INTAKE SYSTEMS FOR VEHICLES LISTED ARE 50 STATE LEGAL. SEE KNFILTERS.COM FOR CARB STATUS ON EACH PART FOR A SPECIFIC VEHICLE.

INSTALLATION INSTRUCTIONS

57-2606
FORD
2018-21 Mustang
L4-2.3L Ecoboost



Note: The OEM air box and its Hydrocarbon Trap are retained.

TOOLS NEEDED:

- flat blade screw driver
- 3/4" wrench

PARTS LIST:

Description	Qty.	Part #
A HOSE CLAMP #36	1	08530
B HOSE; 2.25"ID TO 2.5"ID X 2.5"L	1	08638
C HOSE CLAMP #40	1	08554
D INTAKE TUBE (MY)	1	087391
E VENT; 1/4 NPT QUICK	1	082628
F HOSE CLAMP #60 STAINLESS	2	08628
G HOSE; 3-13/16"ID TO 3.75"ID	1	08683
H AIR FILTER	1	33-5029

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

NOTE: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE INTAKE TUBE, THROTTLE BODY AND ENGINE.

TO START:

1. Turn off the ignition and disconnect the negative battery cable.
NOTE: Disconnecting the negative battery cable erases pre-programmed electronic memories. Write down all memory settings before disconnecting the negative battery cable. Some radios will require an anti-theft code to be entered after the battery is reconnected. The anti-theft code is typically supplied with your owner's manual. In the event your vehicles anti-theft code cannot be recovered, contact an authorized dealership to obtain your vehicles anti-theft code.




2. Loosen the hose clamp that secures the factory intake tube to the air filter housing.



3. Loosen the hose clamp that secures the factory intake tube to the turbo inlet.



4. Disconnect the BOV hose and crank case vent line from the factory intake tube and then remove the tube from the vehicle.
NOTE: K&N Engineering, Inc., recommends that customers do not discard factory air intake.



5. Release the clips that secure the upper air filter housing, remove the housing and factory air filter. Install the provided K&N® air filter and then reinstall the lid and secure with the factory clips.



6. Install the provided coupling hose (08638) onto the turbo inlet and secure with the provided hose clamp.



7. Install the provided quick disconnect fitting into the K&N® intake tube as shown.

NOTE: Plastic NPT fittings are easy to cross thread. Install the vent fitting "hand" tight, then turn it two complete turns with a wrench.



8. Install the provided hump coupler (08683) onto the K&N® intake tube, Install the intake tube into the coupler on the turbo and align the coupler with the air filter housing. Position the coupler onto the air filter housing and adjust the assembly for best fit. Secure the tube and couplers with the provided hose clamps.



9. Connect the BOV hose and crank case vent hoses to the K&N® intake tube.



10. Reconnect the vehicle's negative battery cable. Double check to make sure everything is tight and properly positioned before starting the vehicle.

11. The C.A.R.B. exemption sticker, (attached), must be visible under the hood so that an emissions inspector can see it when the vehicle is required to be tested for emissions. California requires testing every two years, other states may vary.

12. It will be necessary for all K&N® high flow intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void warranty.

ROAD TESTING:

1. Start the engine with the transmission in neutral or park, and the parking brake engaged. Listen for air leaks or odd noises. For air leaks secure hoses and connections. For odd noises, find cause and repair before proceeding. This kit will function identically to the factory system except for being louder and much more responsive.

2. Test drive the vehicle. Listen for odd noises or rattles and fix as necessary.

3. If road test is fine, you can now enjoy the added power and performance from your kit.

4. K&N Engineering, Inc., requires cleaning the intake system's air filter element every 100,000 miles. When used in dusty or off-road environments, our filters will require cleaning more often. We recommend that you visually inspect your filter once every 25,000 miles to determine if the screen is still visible. When the screen is no longer visible some place on the filter element, it is time to clean it. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.

INTAKE SYSTEMS FOR VEHICLES LISTED ARE 50 STATE LEGAL. SEE KNFILTERS.COM FOR CARB STATUS ON EACH PART FOR A SPECIFIC VEHICLE.