



Equipped with AEM® Dryflow™ Filter

No Oil Required!

INSTALLATION INSTRUCTIONS

PART NUMBER: 22-408

1994-1997	HONDA Accord	L4-2.2L	C.A.R.B. E.O. # D-670
1994-1995	HONDA Accord EX	L4-2.2L	C.A.R.B. E.O. # D-670

* **NOTE:** Legal in California only for racing vehicles which may never be used upon a highway

PARTS LIST

Description	Qty.	Part Number
Air Filter Assy. 2.50 X 5" Dry Ele.	1	21-201DK
Short Pipe	1	2-4081
Hose; 5/16ID X 12"L	1	5-2012
Hose; 3/8"ID X 16"L	1	5-1016
Hose, Silicone 2.50x3" Blk.	1	5-250
Mount, Rubber 1" X 6mm	1	1228599
Filter, Vacuum	1	21-300
Grommet, 3/8"	1	784633
Grommet, 1/2"	1	784634
Vacuum Cap, 1/8"	1	8-105
Washer, 6mm Soft Mount	1	559999
Nut, M6 Hex Serrated	1	444.460.04
Hose Clamp, 3/4"	4	4093-5
1/2" Bnd. Hose Clamp, 2.15-3.00"	2	9440
1/2" Bnd. Hose Clamp, 2.31-3.25"	1	9444

Read and understand these instructions BEFORE attempting to install this product. Failure to follow installation instructions and not using the provided hardware may damage the intake tube, throttle body and engine.

1. Preparing Vehicle

- a. Make sure vehicle is parked on level surface.
- b. Set parking brake.
- c. If engine has run in the past two hours, let it cool down.
- d. Disconnect negative battery terminal.
- e. Do not discard stock components after removal of the factory system.

2. Removal of stock system

- a. Disconnect breather hose and any vacuum lines (if they are present) from the air inlet tube.
- b. **CAUTION: Ensure the engine is completely cool before removing the coolant hose, or hot coolant will escape from the cooling system and cause injury or damage. Be sure to capture any lost coolant in a clean container.**

Disconnect the water bypass hose from throttle body or the fast idle thermo valve, if equipped; located at the lower portion of the throttle body. Disconnect the opposite side of the water bypass hose, which runs to either the intake manifold or the water outlet neck. Remove the entire water bypass hose and breather hose assembly from the vehicle. Disconnect the intake air bypass control valve hose where applicable.

- c. Loosen and remove the air inlet tube from the throttle body.
- d. Loosen and remove the stock air box from the vehicle.

NOTE: It is not necessary to remove the stock resonator from inside the fender well.


3. Installation of AEM[®] intake system.

- a. When installing the intake system, do not completely tighten the hose clamps or mounting hardware until instructed to do so.
- b. Some applications use vacuum lines that are connected to the stock air inlet pipe. If this is the case in your application, then the smallest of the rubber grommets must be installed into the pipe. Be sure that these are properly seated to avoid an air leak.
- c. Some applications retain the O.E. PCV breather pipe. If the O.E. PCV pipe lines up with a hole then install the 3/8" I.D. grommet into the hole. If the O.E. PCV pipe lines up with a nipple then move to the next step.
- d. Install one black connector hose on the throttle body end of the inlet pipe. That is the end closer to the breather nipple.
- e. Install two hose clamps on the connector hose and just snug them down on the hose.
- f. Slide the throttle body end of the inlet pipe onto the throttle body.
- g. Gently tighten the hose clamps so that the pipe can still be rotated.
- h. **NOTE: If your application does not have a support tab then skip to step 3i.**

Some applications have a support tab that is welded onto the inlet pipe.

- i. The support tab on the inlet pipe will line up with a threaded hole on the inner fender well. Install the rubber isolator mount and attach the air inlet tube onto the rubber mount. Install the large fender washer and the lock nut onto the isolator mount stud and snug it down.

NOTE: Failure to install the rubber mount will void all warranties of the AEM[®] intake system. On the following page there is a diagram of how the rubber mount should be installed.



- i. Install the air filter.
 - i. Install the AEM[®] air filter onto the end of the inlet tube. Push the filter on around 2 inches over the inlet pipe and install one hose clamp to secure the filter on to the inlet pipe. Once fitment is checked, you can either push the filter on to the inlet pipe more or less depending on clearances. Tighten the hose clamp after this is done. Be sure to leave ample clearance between the filter and any surrounding components.
 - j. Connect the breather hose between the valve cover and the inlet pipe using the breather hose and two clamps supplied with the kit. Connect the new supplied water bypass hose and clamps to the throttle body or the fast idle thermo valve, where equipped, and either the intake manifold or the water outlet neck disconnected earlier.

NOTE: Replace any coolant recovered during hose removal by replenishing the recovery tank.
 - k. Install the short plastic connector fitting into the stock vacuum lines. Then slide the other end of the fitting into the grommet that it lines up with. Make sure that it will not leak.
 - l. If your O.E. PCV breather pipe lines up with a grommet then slide the pipe into the grommet. If your O.E. PCV breather pipe lines up with a nipple then install the 2" long breather hose included in the kit, and secure it with the hose clamps supplied in the kit.

NOTE: Some 90-97 Honda Accords have an intake air resonator valve located within the O.E. resonator box. Since this part of the O.E. air intake system is not being reused upon the installation of the AEM[®] intake system, the vacuum line running from it to the intake manifold must be removed and plugged using the vacuum cap included. Simply follow the vacuum line from the resonator box to the intake manifold. Disconnect the vacuum line from the intake manifold and then install the rubber plug.

NOTE: Some models are equipped with a Fuel Injection Air (FIA) control system. If your model is equipped with a FIA control system it will have a vacuum line that runs from the FIA control valve to the air inlet pipe. During the installation of the AEM[®] intake system this vacuum line should be removed. Install a vacuum foam filter onto the exposed nipple of the FIA control valve.

4. Reassemble Vehicle

- a. Position the inlet pipes for the best fitment. Be sure that the pipes or any other components do not contact any part of the vehicle. Tighten the rubber mount, all bolts, and hose clamps.
 - i. Be sure that the rubber mount is not stressed in any way that may lead to premature failure.
- b. Check for proper hood clearance. Re-adjust pipes if necessary and re-tighten them.
- c. Inspect the engine bay for any loose tools and check that all fasteners that were moved or removed are properly tightened.

- d. Reconnect negative battery terminals and start engine. Let the vehicle idle for 3 minutes. Perform a final inspection before driving the vehicle.

5. CARB Sticker Placement

- a. The C.A.R.B. exemption sticker, (attached), must be visible under the hood so that an emissions inspector can see it when the vehicle is required to be tested for emissions. California requires testing every two years, other states may vary.

6. Service and Maintenance

- a. It is recommended that you service your AEM[®] Dryflow™ filter every 20,000 miles for optimum performance. Use AEM Dryflow cleaning kit part # 21-110.
- b. Use aluminum polish to clean your polished AEM[®] intake tube.
- c. Use window cleaner to clean your powder coated AEM intake tube. **(NOTE: DO NOT USE aluminum polish on powder coated AEM[®] intake tubes)**

<p>For technical inquiries e-mail us at sales@aemintakes.com or call us at 800.992.3000</p>

AEM Air Intake System Warranty Policy

AEM[®] warrants that its intake systems will last for the life of your vehicle. AEM will not honor this warranty due to mechanical damage (i.e. improper installation or fitment), damage from misuse, accidents or flying debris. AEM will not warrant its powder coating if the finish has been cleaned with a hydrocarbon-based solvent. The powder coating should only be cleaned with a mild soap and water solution. Proof of purchase of both the vehicle and AEM intake system is required for redemption of a warranty claim.

This warranty is limited to the repair or replacement of the AEM part. In no event shall this warranty exceed the original purchase price of the AEM part nor shall AEM be responsible for special, incidental or consequential damages or cost incurred due to the failure of this product. Warranty claims to AEM must be transportation prepaid and accompanied with dated proof of purchase. This warranty applies only to the original purchaser of product and is nontransferable. Improper use or installation, use for racing, accident, abuse, unauthorized repairs or alterations voids this warranty. AEM disclaims any liability for consequential damages due to breach of any written or implied warranty on all products manufactured by AEM. Warranty returns will only be accepted by AEM when accompanied by a valid Return Merchandise Authorization (RMA) number. Credit for defective products will be issued pending inspection. Product must be received by AEM within 30 days of the date RMA is issued.

If you have a warranty issue, please call (800) 992-3000 and our customer service department will assist you. A proof of purchase is required for all AEM warranty claims.