

# SPECTRE®

## Performance

### Intake Installation Instructions

P/N 9056

Year/Make/Model/Engine

2005-20 Toyota Tacoma 2.7L

NOT LEGAL FOR SALE OR USE ON ANY POLLUTION CONTROLLED MOTOR VEHICLE IN CALIFORNIA OR STATES ADOPTING CALIFORNIA EMISSION PROCEDURES.

See Spectreperformance.com for CARB status on each part for a specific vehicle



Parts List

- 1- Intake Tube
- 2- M4 machine screws
- 1- Heat shield
- 1- Bulb seal
- 1- Air Filter
- 1- 6" Hose Clamp
- 1- Velocity Adapter
- 1- 3" Flex Coupler
- 1- 2.75" Coupler
- 4- 3" Hose Clamps
- 1- M8 Bolt
- 1- M8 Flat Washer
- 1- 4MM Hose

Tools Required:

- Ratchet
- 10mm socket
- 12mm socket
- 14mm socket
- 5/16 or 8mm nut driver
- 8 inch extension
- Torx 6 socket or 4mm socket
- Phillips screwdriver

For filter reorders ask at the special order counter of your local parts store or call:

1-909-673-9800

ask for: P/N HPR9892 (red filter)

P/N HPR9892B (blue filter)

P/N HPR9892K (black filter)



### Step 1

**Safety first!** Before you begin the installation, make sure that the vehicle is in park (or neutral for a manual transmission) with the parking brake set. Disconnect the negative battery terminal and verify that all components that are listed are present. **Note:** This kit was designed and tested on a stock engine without any custom tuning done to the engine computer. Removing the battery cable may erase the programmed radio stations. The anti-theft code will need to be entered into some radios after the battery cable is connected. The anti-theft code can typically be found in the owner's manual or at your local dealership.

---




### Step 2

Disconnect the mass air sensor electrical connection and unclip the wire harness retaining clips.



### Step 3

Remove the 2 bolts securing the pressure sensor to the stock intake. **Note:** These bolts will be reused in a later step.



### Step 4

Remove the 3 bolts that secure the intake plenum to the engine and loosen the hose clamp at the throttle body.

---




### Step 5

Unlatch the upper air box retaining clips, disconnect the fuel pressure regulator and crank case vent hoses and then lift the intake assembly off the throttle body as shown. Disconnect the wire harness retaining clip shown from the intake plenum.



### Step 6

Remove the 3 lower air box retaining bolts shown and then remove the lower air box from the vehicle.



### Step 7

Install the provided edge trim onto the heat shield as shown.



**Step 8**  
Install the heat shield and secure it using the provided hardware.



**Step 9**  
Secure the heat shield using the stock hardware in the 2 places as shown.



**Step 10**  
Install the filter onto the heat shield using the 3" flex coupler and the provided hose clamps as shown.



**Step 11**  
Install the provided coupler onto the throttle body and secure with the provided hose clamps.



**Step 12**  
Remove the 2 mass air sensor retaining screws and then remove the mass air sensor from the factory air box.



**Step 13**  
Install the mass air sensor into the Spectre intake tube and secure with the provided hardware.



**Step 14**  
Install the Spectre intake tube onto the throttle body and into the flex coupler in the heat shield. Secure the tube by tightening the hose clamps at the couplers.




**Step 15**  
Connect the fuel pressure regulator hose, and the crank case vent hose to the intake tube. Connect the mass air sensor electrical connection as shown. Install the pressure sensor onto the Spectre intake using the bolts removed in Step 3.



#### Step 16

**Make sure that all clamps and hardware are fully tightened. Reconnect the battery cable and start the engine and let it warm up. Shut it off and inspect the installation once more for any loose clamps, wires, or hardware. Test drive & enjoy! Your installation is now complete. Periodically check all clamps and brackets.**

**If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.**

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

**NOT LEGAL FOR SALE OR USE ON ANY POLLUTION CONTROLLED MOTOR VEHICLE IN CALIFORNIA OR STATES ADOPTING CALIFORNIA EMISSION PROCEDURES.**

See [Spectreperformance.com](http://Spectreperformance.com) for CARB status on each part for a specific vehicle

**SPECTRE**<sup>®</sup>  
*Performance*

(909) 673-9800

[www.spectreperformance.com](http://www.spectreperformance.com)

© 2019 SPECTRE PERFORMANCE Made in China

176250A  
11/24/20