# **Product information**

# JetClean Plus



#### **Description**

Specifically designed for swift and effective cleaning of both Gasoline and Diesel fuel systems. It removes deposits and corrects fuel delivery problems. Use the included Universal Adapter Kit (part no. 7911) to connect the device (additional adapter kits are available). Use only with Pro-Line JetClean Gasoline System Cleaner Concentrate (part no. 20312) or Diesel Purge (part no. 2005).

## **Properties**

- cleans the injection system as well as the intake
- for cleaning gasoline and diesel injection systems
- simple to use
- rapid cleaning
- operated without need for electricity or compressed air

#### Areas of application

Suitable for use in all gasoline and diesel engines, with or without turbochargers. Safe for use with catalytic converters and particulate filters (DPF). For professional use only.

## **Application**

Connect the device to the vehicle according to the vehicle type and injection system. Pour at least 2 Liters (0.4 gal.) of the Pro-Line JetClean cleaning fluid into the tank of the device. Depending on the vehicle, pressurize the device with the system pressure required for cleaning. The pressure can be controlled either manually using the hand pump or through the compressed air system with the aid of the compressed air connection provided. Open the ball valve located on the hoses according to the connection and vehicle type and start the engine. Let the engine run on idle and give occasionally short bursts up to 2500 - 3000 rpm. The pressure fluctuations this causes will help to remove stubborn dirt. The cleaning process takes about min. 30-45 minutes, depending on the level of contamination. Then assemble the vehicle to its original condition, check for leaks and do a test drive of at least 10 km (6 miles).

**Observe:** Make sure when attaching and removing the device to and from the vehicle that the fuel and the cleaning fluid do not ignite on heat sources and that the lines of the device are not in direct contact with any heat sources such as the exhaust system during cleaning. After each service empty the JetClean unit and fill the remaining cleaning fluid in a suitable container.



### Available pack sizes

1 Piece Carton

5118

D-GB-I-E-P-RUS

Our information is based on thorough research and may be considered reliable, although not legally binding.