



A6 RUNNING BOARDS

Assembly, Installation, Operation,
and Maintenance Instructions


PART NUMBER	AL6001B
INSTALL TIME	120 MINUTES

2015-2024 CHEVY COLORADO / GMC CANYON CREW CAB

DEALER / INSTALLER	Provide a copy of these instructions to the end user of this product. These instructions provide important operating and safety information for proper usage of this product. Demonstrate the proper use of the product with the end user. Have the end user demonstrate that they understand the proper use of the product.
END USER	Read and follow all instructions included in this manual. Ask your Dealer / Installer for assistance if you do not understand the proper use of the product. Never remove any decals from the product. Failure to follow these instructions can result in injury or death.

PACKAGE CONTENTS

AR3 RUNNING BOARDS (76in)	2	8-1.25mm X 25mm HEX BOLTS	12
MOUNTING BRACKETS	6	8mm X 24mm X 2mm FLAT WASHERS	24
8mm T-BOLTS	12	8mm LOCK WASHERS	24
8-1.25mm CLIP-ON NUTS	12	8mm HEX NUTS	12




PROCEDURE


REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED.

1. Start the installation under the passenger/right side of the vehicle. Locate the front factory running board mounting location along the bottom and inner side of the body panel, **(Figures 1 & 2)**. **NOTE:** Hold a Bracket up in place to help determine the mounting holes to use along the bottom and inner side of the body.
2. Remove the rubber plugs from the front location, **(Figure 2)**. Select (2) 8mm Clip Nuts. Slide each Clip Nut into the large hole and over the smaller hole next to it, **(Figure 3)**. Line up threaded nut on the Clip Nut with smaller hole in body panel.
3. Select (1) Mounting Bracket, **(Figure 4)**. Attach the Bracket to the (2) Clip Nuts with (2) 8mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers. Snug but do not fully tighten the hardware. **NOTE:** Brackets are universal and will fit passenger/right and driver/left sides of the vehicle.
4. Move to the next mounting location along the body, **(Figures 1 & 2)**. Repeat **Steps 1-3** to install (1) Mounting Bracket in the center location.


Passenger/Right Side Installation Pictured




(Figure 1) Passenger side mounting locations along bottom and back of body panel illustrated.



(Figure 2) Remove rubber plugs from front and center mounting locations (arrows).



(Figure 3) Slide 8mm Clip Nut into large hole and over small hole.




(Figure 4) Attach Mounting Bracket to Clip Nuts.

PROCEDURE (CONTINUED)


5. Next, locate the rear mounting location at the back of the cab, **(Figure 5)**. Repeat **Steps 1-3** to install (1) Mounting Bracket in the rear location.

6. Carefully unwrap the Running Boards. Select (1) Running Board. Insert (3) 8mm T-Bolts into each channel in the bottom of the Running Board, **(Figure 6)**.

Driver/Left Side Installation Pictured



(Figure 5) Passenger/right rear mounting location.



(Figure 6) Insert (3) 8mm T-Bolts into each channel in the bottom of the Running Board.

PROCEDURE (CONTINUED)


7. With assistance, place the Running Board on top of the Brackets. Guide the T-Bolts in the Running Board down through the slots in the Brackets, (**Figures 7-10**). **IMPORTANT:** Do not slide, (front to back), the Running Board on the Brackets or damage to the finish may result.

8. Attach the Running Board to the Brackets with (6) 8mm Flat Washers, (6) 8mm Lock Washers and (6) 8mm Hex Nuts, (**Figures 7-10**). Do not tighten hardware.

9. Slide the Running Board forward or back and in/out as desired. **IMPORTANT:** Do not allow the front of the Running Board to come in contact with front splash guards if equipped. Level and adjust the Running Board as necessary and fully tighten all hardware.


Driver/Left Side Installation Pictured

8mm Flat Washer
8mm Lock Washer
8mm Hex Nut




(Figure 8) Attach Running Board to passenger/right center Bracket.

8mm Flat Washer
8mm Lock Washer
8mm Hex Nut




(Figure 9) Attach Running Board to passenger/right rear Mounting Bracket.

8mm Flat Washer
8mm Lock Washer
8mm Hex Nut



(Figure 7) Attach Running Board to passenger/right front Bracket.



(Figure 10) Passenger/right Running Board installed.


PROCEDURE (CONTINUED)

10. Repeat **Steps 1-9** for driver/left side Running Board installation. **NOTE:** Measure the distance from the passenger/right front wheel opening to the front of the Running Board, **(Figure 11)**. Apply this distance to the driver/left Running Board and fully tighten all hardware.

11. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

To protect your investment, Do not use any type of polish or wax that may contain abrasives that could damage the finish. Mild soap may be used to clean the Running Board.

Driver/Left Side Installation Pictured



(Figure 11) Measure distance from end of passenger/right Running Board to front wheel opening. Match driver/left Running Board.



PRODUCT CARE

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- Use ONLY Non-Abrasive automotive wax. Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Mild soap may be used to clean the product for Black finish.

FAQs

Hardware and mounting brackets are not aligning properly.	Ensure that hardware is being used on the correct side of vehicle. In some cases, the hardware may appear the same for driver and passenger side but may alter the alignment of mounting location. Check mounting brackets for both sides.
Products are thumping / rattling after Installation.	Ensure that all required mounting brackets/hardware's are installed & tightened correctly. Suggest using white Lithium/regular grease between metal-to-metal contact.
Missing / Excess Hardware.	Recheck hardware count as per the part list.
Product not installing properly.	Ensure the Year/Make/Model as well as cab and bed dimensions are correct for the application. Review all steps for installation to ensure they were followed correctly.
Who should be contacted for questions regarding product / installation assistance?	www.trailfx.com / support@trailfx.com or 1-(866) 638-4870

CONTACT US

WEBSITE: TrailFX.com

PHONE: 1-866-638-4870

EMAIL: support@trailfx.com

WARRANTY TERMS

Black Powder Coated: Limited Lifetime Warranty

TrailFX and Keystone Automotive Operations Inc. make no guarantees or warranties for products not manufactured by Keystone Automotive Operations Inc. Such products are covered solely under any applicable warranty of the manufacturer. It is always recommended that the operating instructions and warranty instructions provided by the manufacturer are followed.

Keystone Automotive Operations Inc. warrants its products to be free from manufacturing and material defects to the original purchaser for the length of warranty stated above from the date of retail purchase. If any products are found to have a manufacturing or material defect, the product will be replaced or repaired at the option of TrailFX and Keystone Automotive Operations Inc. with proof of purchase by the original purchaser. The original purchaser shall pay all transportation and shipping costs associated with the return of the defective product and the defective product shall become the property of Keystone Automotive Operations Inc.

This Warranty applies to Keystone Automotive Operations Inc. products used for individual and recreational purposes. Commercial usage of the Keystone Automotive Operations Inc. products limits the warranty to 90 days from the date of purchase.

This Warranty applies only to Keystone Automotive Operations Inc. products which are found to be defective in manufacturing or material. This warranty does not apply to normal wear and tear of the finish placed on Keystone Automotive Operations Inc. products.

TrailFX and Keystone Automotive Operations Inc. are not responsible for any labor costs incurred for removal or replacement of the defective product.

TrailFX and Keystone Automotive Operations Inc. are not responsible for repair or replacement of any product under the limited warranty where the product was improperly installed, misapplied, altered, abused, neglected, overloaded, misused, or damaged as a result of an accident, including any use of the product not in accordance with all products operating and safety instructions.

Without limiting the generality of the foregoing, TrailFX and Keystone Automotive Operations Inc. shall under no circumstances be liable for any incidental or consequential loss or damage whatsoever arising out of, or in any way relating to any such breach of warranty or claimed defect in, or non-performance of the products. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.

This limited warranty gives you specific legal rights, and you may also have other rights that vary from state to state.