

INSTALLATION MANUAL

69549C

Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Weight Carrying Capacity

Gross trailer weight (GTW) 6,000 lbs.

Tongue weight (TW) 900 lbs.

Weight Distribution Capacity

Weight distribution (WD) 8,000 lbs.

WD tongue weight (WDTW) 900 lbs.

Parts List

Item	Qty	Description
1	6	Hex bolt, M14-1.50 x 40mm, CL 10.9
2	6	Conical-toothed washer, 9/16"

Tools Required

Ratchet	Torque wrench
Socket, 22mm	Socket extension, 6"
Wire pipe brush	--

⚠ WARNING

Never exceed the vehicle manufacturer's recommended towing capacity.

Product Photo



NOTICE

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

This installation requires no drilling.

Periodic inspection of the trailer hitch should be performed to ensure all mounting hardware remains tight and structural components are secure.

To help prevent damage to the product or vehicle, refer to the specified torque specifications when securing hardware during the installation process.

SAFETY INSTRUCTIONS

Safety glasses should be worn at all times while installing this product.




Warranty Information

Our products are backed by industry-leading warranties. For a copy of the product warranties or to provide feedback, please contact our support line using the phone number at the bottom of this document.

ASSEMBLY


Parts List

Item	Qty	Description
1	6	Hex bolt, M14-1.50 x 40mm, CL 10.9
2	6	Conical-toothed washer, 9/16"



Step 1

Lower the spare tire from the inside of the vehicle by using the tools under the storage compartment.



Step 2

Weldnut cleaning may be required.

Raise the trailer hitch into position and secure with the provided M14 hardware (#1, #2).

Torque all M14 bolts to 139 lb-ft.



Step 3

Raise the spare tire back into place following the instructions from Step 1.



Final Installed Image

