


Class III Receiver Hitch Part No. 69614C



Fits: SUBARU CROSSTREK



GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 3,500 LBS. TRAILER WEIGHT & 525 LBS. TONGUE WEIGHT.
WARNING: *** DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY. ***



			Parts List	FISHWIRE TECHNIQUE		
TEM QTY PART NUMBER DESCRIPTION				INSERT COILED END OF FISHWIRE TOOL THROUGH HITCH MOUNTING HOLE IN VEHICLE FRAME RAIL		
1	4	10-10287	BOLT,CAR,1/2-13 UNC,1-1/2,GRD8,YZ	AND OUT THE ACCESS HOLE. PASS COILED END OF FISHWIRE THROUGH SPACER AND		
2	4	CM-SP6	.250 x 1.00 x 3.00" SQUARE HOLE SPACER	_ BOLT AS SHOVIN. PULL		
3	2	CM-SP16	.250 x 1.50 x 2.00" ROUND HOLE SPACER	BOLT THROUGH FRAME		
4	4	20-00062	NUT, SER-FLANGE,1/2-13 UNC,GRD8,YZ	AND OUT MOUNTING HOLE. USE FISHWIRE TO GUIDE HITCH DURING MOUNTING AND PREVENT LOSS OF BOLT /		
5	4	1_2 FISHWIRE	1/2" FISHWIRE	SPACER INSIDE FRAME RAIL. **NOTE: SOME VEHICLES MAY FISHWIRE THROUGH END OF FRAME**		
ATTA AND S THE B	CH FIS SLIDE BOLT ER (A	E PULL FISHWIRE ECHNIQUE SHWIRE TO CARRIA SPACER ONTO FIS THRU THE HOLE FC AS SHOWN). PULL E PROTRUDING FROM	HWIRE. PUSH PLLOWED BY THE BOLT BACK INTO	PASSENGER SIDE FRAME RAIL		
	T	OOLS REQUIF RATCHET 3/4" SOCKE DIE GRINDEI ORQUE WREN AFETY GLASS	T R NCH			
	F	RIVER SIDE		5		
1		CESS HOLE BOTH SIDES				
	LE	PACERS TO EVEL HITCH REQUIRED	1			
	0.114	(FIGUE - 04 - 150				
		<u>VEIGHT: 31</u> LBS				
		<u>. TIME</u>				
		ESSIONAL: <u>30</u> M				
		DE (DIY): <u>60</u> MIN	IUTES			
NS ⁻	TALL	. NOTES:				
_	ΙΔ ΙΙΛ:	RGE ACCESS HO	I FS	ALLAS		
	יית שוווו.					

INSTALLATION STEPS

- REVERSE FISHWIRE HARDWARE

- 1. Remove (2) rubber plugs from each frame rail and return to vehicle owner (leave center plugs in the frame).
- 2. Enlarge access holes and fishwire 1/2" carriage bolts and CM-SP6 spacers into position and reverse fishwire remaining 1/2" carriage bolts and CM-SP6 spacers into access hole. Leave fishwires attached.
- 3. Raise hitch into position using CM-SP16 spacers to level hitch as necessary. Remove fishwires and loosely install (4) 1/2" hex flange nuts. **NOTE:** Be careful not to push the bolts into the frame.
- 4. Torque all 1/2" fasteners to 110 lb-ft.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Keystone Automotive Operations Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Keystone Automotive Operations Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Keystone Automotive Operations Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684. For Technical & Warranty Support: 1-877-544-4449 Fax- 1-855-242-8922 www.huskytow.com