




Class III Receiver Hitch Part No. 69643C



Fits: AUDI Q5




GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 5,000 LBS. TRAILER WEIGHT & 750 LBS. TONGUE WEIGHT.
GROSS LOAD CAPACITY WHEN USED AS A WEIGHT DISTRIBUTION HITCH: N/A LBS. TRAILER WEIGHT & N/A LBS. TONGUE WEIGHT.



WARNING: * DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY. *****

TOOLS REQUIRED

RATCHET
TORQUE WRENCH
6" SOCKET EXTENSION
10mm/16mm SOCKETS
T20/T25 TORXBIT SOCKETS
PANEL REMOVAL TOOL
MASKING TAPE
AVIATION SHEARS
SAFETY GLASSES



HITCH WEIGHT: 36 LBS.


INSTALL TIME

PROFESSIONAL: 60 MINUTES

NOVICE (DIY): 120 MINUTES

INSTALL NOTES:

- NO DRILLING REQUIRED
- TEMPORARILY REMOVE BUMPER FASCIA, BUMPER BEAM, AND BUMPER BEAM BRACKET
- TRIMMING REQUIRED



INSTALLATION STEPS

1. Remove (4) screws from the bottom of the bumper fascia and (2) screws from the bottom inside of the wheel well, (1) in each wheel well, using a T25 torxbit socket.
2. Pull away wheel well lining to reveal (6) screws, (3) on each side, and remove using a T25 torxbit socket.
3. Pull away wheel well trim to reveal screw and remove using a T25 torxbit socket. Open liftgate to reveal (2) screws. Remove using T20 torxbit socket.
4. Remove trunk floor and use plastic pry tool to remove trunk edge trim starting from the side.
5. On the inside of the trunk locate (2) rubber plugs, (1) on either side, and use the pry tool to remove plugs to access (2) nuts, (1) on either side, and remove using 10mm socket.
6. Remove access panel on either side of trunk and locate (2) nuts, (1) on either side, and remove using a 10mm socket.
7. Gently remove bumper fascia starting from the sides and working towards rear of car. Set aside for later reinstallation. Locate (8) M10 bolts on the bumper beam and remove using a 16mm socket. Remove bumper beam and bumper beam bracket.
8. Raise hitch into position along with the bumper beam and bumper beam bracket and secure with hardware removed from step 7. Torque M10 hardware to 45 ft-lbs.
9. Temporarily unhook the kick sensor wire from the clips. Using masking tape, mark out the 3.25" section in-between the center sensor clips and trim using aviation shears. Reinstall bumper fascia to vehicle following step 7 in reverse order and reattach the kick sensor wire. Follow steps 1-6 in reverse order to complete installation.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Keystone Automotive Operations Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Keystone Automotive Operations Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Keystone Automotive Operations Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684. For Technical & Warranty Support : 1-877-544-4449 Fax- 1-855-242-8922 www.huskytow.com

12/8/2020