



ITEM	DESCRIPTION	QTY
1	BUMPER BRACKET	1
2	M6 X 20MM HEX BOLT	2
3	1/4" FLAT WASHER	2

Refer to this LOT NUMBER when contacting customer service: _____

PLEASE READ BEFORE STARTING INSTALLATION

While MBRP has made every effort to ensure that all components of this system are of superior quality and properly packaged, it is the installer's responsibility to ensure the following:

- that ALL components shown above are present.
- that ALL mating components fit together.
- that there are no damaged components.
- that the system you have purchased is appropriate for your vehicle year, model and configuration.
- that the system will not interfere with any modifications previously installed or planned.
- that you have read and understand these instructions.

If you have any questions or are uncertain about any aspect of the installation of this system to your vehicle please contact your dealer before commencing installation.

TRIMMING OF THE PLASTIC BUMPER VALANCE MAY BE REQUIRED TO FIT SOME VEHICLES

1. Mount then assemble the desired light assembly combination onto the **Bumper Bracket** prior to installing on vehicle. If vehicle is equipped with an engine block heater, the plug will need to be relocated to use the outside passenger-side mounting position on the bracket.

Refer to Figure 1.

VEHICLES EQUIPPED WITH ADAPTIVE CRUISE CONTROL MAY NEED TO REMOVE BUMPER VALANCE FOR INSTALLATION

2. Remove the plastic rivets and bolts securing the bumper valance. Remove the two bolts securing the bottom of the license plate bracket if equipped. Retain all hardware for installation.

Refer to Figure 2.

3. Gently pull the bumper valance to disengage retaining clips. Disconnect the front distance sensor connector to remove the valance from vehicle, if equipped. Set aside the valance and all hardware, retaining for installation.

4. Remove the two bolts securing the adaptive cruise control sensor bracket to the bumper structure, retain for installation.

Refer to Figure 3.

5. Install the **Bumper Bracket** with the desired light assemblies fitted on top of the OEM sensor bracket using the retained bolts. If vehicle is not equipped with adaptive cruise control, use supplied **Hex Bolts** and **Flat Washers**.

Refer to Figure 3.

6. Reinstall the OEM front bumper valance if removed, starting by re-connecting the distance sensor connector, if equipped, reversing steps 2 through 4 above.

Refer to Figure 6.



Figure 1



Figure 2



Figure 3



Figure 4



Congratulations! You are ready to begin outfitting your vehicle with your **MBRP** performance bumper light bracket. We know you will enjoy your purchase.