


**SL9219-02**2024-UP Can-Am MAVERICK R,  
40" CURVED ROOF LIGHT KIT**MBRP**

ITEM	DESCRIPTION	QTY
1	LEFT-SIDE LIGHT BRACKET	1
2	RIGHT-SIDE LIGHT BRACKET	1
3	LIGHT BAR	1
4	M8X16 SCREW	2
5	M8 WASHER	2
6	DEFLECTOR	1
7	WIRING HARNESS	1
8	CONNECTOR	1
9	WEDGE LOCK	1
10	SWITCH	1
11	M5X10 SCREW	3
12	M5 T-NUT	3
13	M5 WASHER	3
14	4" CABLE TIE	2
15	8" CABLE TIE	3
16	M6 NUT	2

DETAIL B  
SCALE 1:2

Refer to this LOT NUMBER when contacting customer service: \_\_\_\_\_

**PLEASE READ BEFORE STARTING INSTALLATION**

While MBRP has made every effort to ensure that all components of this kit are of superior quality and properly packaged, it is the installer's responsibility to ensure the following before installation;

- that ALL components shown above are present.
- that ALL mating components fit together.
- that there are no damaged components.
- that the product you have purchased is appropriate for your vehicle year, model and configuration.
- that the product will not interfere with any modifications previously installed or planned.
- that you have read and understand these instructions.

If you have any questions or are uncertain about any aspect of the installation of this kit to your vehicle please contact your dealer before commencing installation.



Figure 1



Figure 2



Figure 3



Figure 4

## Installation

1. Disconnect negative battery lead.
2. Remove the 5 dash panels to allow access for wiring installation.  
Refer to Figure 1.
3. Install the **Deflector** onto the back of the **Light Bar** using the supplied **M5 T-Nuts, M5x10 Screws, and M5 Washers**. The correct orientation is wiring on the right hand side of the SxS, with the **Deflector** mounted below the **Light Bar**. Note, there is an access slot on the backside of the light bar to insert the **M5 T-Nuts**.  
Refer to Figure 2.
4. Remove the forward roof mounting hardware using it to loosely Install the **Left-Side Light Bracket** and **Right-Side Light Bracket**.  
Refer to Figure 3.
5. Install the **Light Bar** and **Deflector** assembly onto the **Light Brackets**. Tighten the **M8x16 Screws**, followed by the **Light Bracket** hardware.
6. Drill a 1" hole in the roof to allow the **Light Bar** wiring connector to pass through. Secure the wiring to the **Right-Side Light Bracket** using the **4" Cable Ties**.  
Refer to Figure 4.




Figure 5



Figure 6

7. Open the Right-Hand access panel at the base of the A pillar. Feed the bare terminal end of the **Wiring Harness** from the dash area, through the wire channel, in through the base of the A Pillar until visible at the top access hole. Use a pick to pull both wires through the access hole.

Refer to Figures 5, 6 and 7.



Figure 7




Figure 8



Figure 9

8. Push the wire terminals through the back of the **Connector**. Be sure to follow the color/pin assignment shown in **Figure 8**. Once fully seated, install **Wedge Lock** with needle nose pliers to secure the terminals in the **Connector**.
9. Connect the **Wiring Harness** to the **Light Bar**.
10. Route the spade connector end of the **Wiring Harness** through the access hole beside the master cylinder reservoir.  
Refer to **Figure 9**.



Figure 10



Figure 11

11. Pull the **Wire Harness** through the firewall and route it to the center console. Remove the 3-place switch bezel and remove one of the cover plates. Install the **Switch** into the bezel. Connect spade terminals to the **Switch**. Be sure to follow color code/pin assignments in **Figure 12**. Reinstall Switch Bezel. Refer to Figures 10, 11 and 12.

# MBRP

PIN	COLOR
2	RED
3	BLUE
6	RED
7	BLACK
8	BLACK




Figure 12




Figure 13




Figure 14

12. Route the wiring harness along the cowl in the wire trough.

**Refer to Figure 13.**

13. Attach the positive red wire to the accessory power post, and the black wire to the negative ground post. Secure with **M6 Nuts**.

**Refer to Figure 14.**

14. Secure the wiring harness along its full length with the supplied **8" Cable Ties**. Ensure it is clear of all steering and pedal components.

15. Install the dash panels removed in step 2.

16. Reconnect negative battery lead.

**Congratulations!** You are ready to experience the improved performance of your **MBRP** Accessory Lighting kit. We know you will enjoy your purchase!