




3" Side Bar

Part No. A0022S/B



Fits: 2012 - 2015


Honda CRV



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.



READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM 45 TO 65 FOOT POUND.



60-180 min



Cutting Not Required



Drilling Not Required



support@trailfx.com




1 866 638 4870

POLISHED STAINLESS STEEL – LIMITED LIFETIME
POWDER COATED BLACK – 3 YEARS

PARTS LIST


Qty	Part Description	Qty	Part Description
1	Driver/Left Sidebar	1	Passenger/Right Rear Mounting Bracket
1	Passenger/Right Sidebar	20	8-1.25mm x 30mm Hex Bolts
1	Driver/Left Front Mounting Bracket	20	8mm Lock Washers
1	Passenger/Right Front Mounting Bracket	20	8mm x 24mm OD x 2mm Flat Washers
1	Driver/Left Rear Mounting Bracket		




Driver Side Installation Pictured Without Plastic Cover for Instruction Purposes Only

INSTALLATION PROCEDURE

1. Identify and separate the driver and passenger side Mounting Brackets. Start installation on the driver/left side of the vehicle. Remove the plastic cover under the driver side of the vehicle, **(Figure 1)**.
2. Locate the (2) 8mm threaded holes in the floor panel next to the pinch weld toward the front of the vehicle. Also locate the threaded holes in the bottom of the inner frame channel in line with the outer holes, **(Figure 1)**. **IMPORTANT:** There are (4) threaded holes at each mounting location, (2) inner on bottom of frame channel and (2) outer next to pinch weld. The single slot in the inner mounting tab on the Brackets will line up with the threaded hole towards the rear of vehicle. **NOTE:** These threaded holes are also used by the vehicle manufacturer for OE running board installation.
3. Hold the driver side front Bracket up in place to verify the location of the correct threaded holes, **(Figures 1 & 5)**. Repeat to verify the rear mounting bracket location on the vehicle. Mark the front and rear mounting locations with a marker for reference.




(Fig 1) Driver Side Front Mounting Location Pictured




(Fig 5) Driver Side Front Mounting Bracket Pictured

4. Cut out the paper template on **Page 4** labeled "Driver Side," (**Figure 2**). Cut out the square section on the bottom and the (2) 8mm holes on the top of the template, (**Figure 3**). Temporarily reinstall the plastic cover, (fasten clips/screws toward outside only). Hold the template up to the outer (2) factory 8mm threaded holes next to the pinch weld as identified in **Step 2**, (**Figure 4**). Use a marker to trace the cut out section on the bottom of the template onto the plastic cover. Repeat this Step to mark the rear bracket location.

Cut out square and
(2) round holes



(Fig 2) Driver Side Template Pictured



(Fig 3) Driver Side Template Pictured


Fold along dashed line




(Fig 4) Rear Driver Side Location Pictured

With the plastic cover in place, hold the paper template (Driver side pictured) over the (2) threaded holes next to the pinch weld. Use a marker to trace the square cut out section on the template. Use a utility knife or hacksaw to carefully cut out this section. Check the clearance between the Bracket and the cover often for proper fit


5. Remove the plastic cover. Cut out the (2) sections as marked. **IMPORTANT:** The templates have been provided for reference use only. It is the installer's responsibility to be absolutely sure that the correct location has been marked before cutting the plastic cover.
6. Select the driver side Front Bracket. Insert the bracket through the hole cut in the cover. Attach the outer end of the driver side front Mounting Bracket to the (2) threaded holes next to the pinch weld with the included (2) 8mm Hex Bolts, (2) 8mm Lock Washers, and (2) 8mm Flat Washers, **(Figure 5)**. Attach the inner tab on the bracket to the threaded hole in the bottom of the inner frame channel with the included (1) 8mm Hex Bolt, (1) 8mm Lock Washer, and (1) 8mm Flat Washer, **(Figure 6)**. Leave hardware loose at this time.
7. Move to the back of the vehicle and repeat **Steps 6 – 7** for rear Bracket installation, **(Figure 7)**.



(Fig 5) Driver Side Front Mounting Bracket




(Fig 6) Driver Side Front Mounting Bracket Pictured



(Fig 7) Driver Side Rear Mounting Bracket Pictured

8. Leave the plastic cover loose and slowly tighten the hardware bolting the Brackets to the vehicle. **NOTE:** It may be necessary to completely remove the Brackets and cover if the cover requires additional cutting. Leave plastic cover loose at this time.
9. Carefully position the Driver/Left Sidebar onto the (2) Mounting Brackets. Attach the Sidebar to the Mounting Brackets using the included (4) 8mm Hex Bolts, (4) 8mm Lock Washers and (4) 8mm Flat Washers, **(Figure 8)**. Do not tighten at this time.





(Fig 8) Driver Side Front Mounting Bracket Pictured

10. Level and adjust the Sidebar and tighten all hardware.
11. Once all hardware has been completely tightened, reinstall the plastic cover with the factory hardware.
12. Repeat **Steps 1 – 11** for passenger Sidebar installation.
13. Do periodic inspections to the installation to make sure that all hardware is secure and tight.



Complete Installation




PARTS IDENTIFICATION GUIDE

Driver Side tube packed using "Green" color foam sheet. Passenger Side tube packed using "White" color foam sheet

No.	Parts Identification
1	Passenger / Right 'Rear' Bracket marked "PR"
2	Driver / Left 'Rear' Bracket marked "DR"
3	Passenger / Right 'Center' Bracket marked "PC"
4	Driver / Left 'Center' Bracket marked "DC"
5	Passenger / Right 'Front' Bracket marked "PF"
6	Driver / Left 'Front' Bracket marked "DF"

Note:

- This guide is to identify the parts and not a reference for part count.
- For part count, refer Parts List.
- Product / Bracket image is representative and actual design may vary.

**PRODUCT CARE**

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- Mild soap may be used to clean the product for both **Stainless Steel and Black finish.**

FAQ's**1. Hardware's are not of correct size.**

In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, ensure that holes are not partially covered with any plastic grommet or rust? If it is, remove the plastic grommet & rust from the thread holes & re-try the installation.

2. Mounting Bracket are not getting Installed properly.

In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.

3. Products are thumping / rattling after installation.

Ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.

4. Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors.

Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Refer Parts identification guide.

5. Missing / Excess Hardware.

Recheck hardware count as per the part list.

6. Product not installing properly.

Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.

Check out these other FX Products!!

www.TrailFX.com

**BULL BAR****GRILLE GUARDS****BED RAILS****RUNNING BOARDS**

Keystone Automotive Operations Inc. (KAO) warrants this product to be free of defects in material and workmanship at the time of purchase by the original retail consumer. KAO disclaims any other warranties, express or implied, including the warranty of fitness for a particular purpose or an intended use. If the product is found to be defective, KAO may replace or repair the product at our option, when the product is returned prepaid, with proof of purchase. Alteration to, improper installation, or misuse of this product voids the warranty. KAO's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for any incidental or consequential loss or damage.